

# PROJECT

## Code Implementation (Object Recognition)

---

LABORATORY SESSIONS

A solid orange horizontal bar at the bottom of the slide.

# OBJECTIVES

---

- Implementation of a Matlab GUI to detect, describe and recognize objects.



# STUDENT'S WORK

---

- Implementation of a Matlab code with a **graphical interface** (GUI or app) aimed to recognize a certain type of objects. Alternatively, any other task related to image processing can be implemented.
- All the required files must be uploaded to PoliformaT:
  - **Matlab files** required to run the developed software. For its evaluation, the code must provide a proper result without errors.
  - **Report** (Word or PDF) with the project documentation.
- Evaluation of the work will take into account the problem's difficulty, code's originality, programming structure and comments, and report's content, quality and presentation.

# STUDENT'S WORK

---

## Report Contents

- Introduction: description of the project's objectives.
- GUI: description of the GUI's layout and objects.
- Code: the code should be commented, specially the key lines of the process. There is no need to include code lines in the report.
- Description of the algorithm: flowchart of the detection process and some sample images summarizing its performance.
- Results: analysis of the code performance with several examples (successful and failed).
- Discussion of results and possible improvements.
- References: sources of information consulted.

# STUDENT'S WORK

---

## Graphical Interface

- The graphical interface in Matlab can be developed by the **GUIDE** tool or the **App Designer**.
- The GUIDE tool is a graphical design environment to develop GUIs (Graphical User Interfaces) in Matlab. This tool will be removed in future Matlab releases.

*Create a Simple App Using GUIDE:*

[https://mathworks.com/help/matlab/creating\\_guis/about-the-simple-guide-gui-example.html](https://mathworks.com/help/matlab/creating_guis/about-the-simple-guide-gui-example.html)


- The App Designer is the recommended environment to build graphical apps in new releases of Matlab.

*Create and Run a Simple App Using App Designer:*

[https://mathworks.com/help/matlab/creating\\_guis/create-a-simple-app-or-gui-using-app-designer.html](https://mathworks.com/help/matlab/creating_guis/create-a-simple-app-or-gui-using-app-designer.html)

# STUDENT'S WORK


## Graphical Interface



GUI\_Example.fig

# STUDENT'S WORK

## Graphical Interface




App\_Example.mlapp



# PROJECT IDEAS

---




Quality control for industry




# PROJECT IDEAS

## Leaf/Fruit Recognition



(a)






(b)



# PROJECT IDEAS

---




## Driving assistance






# PROJECT IDEAS

Sports/games




## Cell counting




# PROJECT IDEAS

## Barcode/Card/Paper Reader



5	3			7				
6			1	9	5			
	9	8					6	
8				6				3
4			8		3			1
7				2				6
	6					2	8	
			4	1	9			5
			8			7	9	



# PROJECT IDEAS

---

## People Detection



# CAMERAS

---

## PC webcams:



- Install *MATLAB Support Package for USB Webcams*
- Matlab code to acquire images/video:

```
camList = webcamlist; % show the connected webcams  
cam = webcam(1); % connect to the webcam (first one)  
preview(cam); % open a video preview window  
img = snapshot(cam); % get a frame  
imshow(img); % show the captured frame
```



# CAMERAS

---

## Android phone:



- Install app *IP Webcam* or similar
- Open the app, start the server and write the IP address
- Matlab code to acquire images/video:

```
img = imread('http://ip_address/shot.jpg'); % read image  
  
cam = ipcam('http://ip_address/video'); % connect to the video stream  
preview(cam); % open a video preview window  
img = snapshot(cam); % get a frame
```



# CAMERAS

## Cabinet camera:



- Matlab code to acquire images/video:

```
img = imread('http://visionartificia.gnd.upv.es/jpg/image.jpg'); % read image  
  
% connect to the video stream  
cam = ipcam('http://visionartificia.gnd.upv.es/mjpg/1/video.mjpg');  
preview(cam); % open a video preview window  
img = snapshot(cam); % get a frame
```

# CAMERAS

## Lab camera:




## PTZ (Pan-Tilt-Zoom)

AXIS M5055 PTZ Network Camera

Live View | Setup | Help

View size: Stream profile: Motion JPEG PTZ preset: Go



Up TILT Down

Video PTZ

PAN Left Right Home

ZOOM Wide Tele Ctrl panel

FOCUS Near Far Auto

BRIGHTNESS

# CAMERAS

---

## Lab camera:



## PTZ camera




- Matlab code to acquire images/video:


```
% connect to the video stream  
cam = ipcam('http://158.42.149.40/mjpg/1/video.mjpg','alumno','tdivtdiv2021');  
preview(cam); % open a video preview window  
img = snapshot(cam); % get a frame
```

# CAMERAS

## Kinect v2 device:



- RGB camera: 1920x1080, 30fps
- Depth camera: 512x424, 30fps
- Detection of 25 skeleton joints
- Six people tracking








# CAMERAS

Kinect v2 device:



Depth image



# CAMERAS

---

## Kinect v2 device:



- Install *Image Acquisition Toolbox Support Package for Kinect For Windows Sensor*
- Matlab code to acquire images/video:


```
depthVid = videoinput('kinect', 2); % RGB camera
colorvid = videoinput('kinect', 1); % depth camera
[depthMap, depthMetaData] = getsnapshot(depthVid); % get RGB frame
[image, imageMetaData] = getsnapshot(colorvid); % get depth frame
cuerpo = depthMetaData.DepthJointIndices; % person skeleton
```

# CAMERAS



## Kinect v2 device:

- Kin2 Toolbox: <https://github.com/jrterven/Kin2>





# CAMERAS



## Kinect v2 device:

- Kin2 Toolbox: <https://github.com/jrterven/Kin2>



# CAMERAS

## Basler industrial cameras:



- Monochrome camera
- 3840x2748 px, 10fps
- GigE Vision Interface




- Install *GigE Vision Support from Image Acquisition Toolbox*
- Matlab code to acquire images/video:


```
gigecamlist; % camera list
cam = gigecam(1); % connect to the camera (first one)
preview(cam); % open a video preview window
img = snapshot(cam); % get a frame
imshow(img); % show the captured frame
g.ScalingHorizontalAbs=0.25; g.ScalingVerticalAbs=0.25; % 1/4 resolution
```

# CAMERAS

## Stereo Vision: 2 cameras & calibration



Depth map



Blur effect